


Edge+ Water Filter and UV-C Lamp Replacement


Replacing the Water Filter:




1. Remove the top panel.




2. Press the tab and lift the clip.



3. Carefully pull the water filter upwards to remove it.



4. Insert the new Water filter and press it down gently.



5. Close the clip until it clicks into place.



6. Reattach the top panel.



Warning!

Do not dispense hot water while replacing the water filter.


Note:

If the water filter is not installed correctly, has expired, or is not a genuine replacement part, an error message will remain on the display until the issue is resolved.

Flushing the New Water Filter




5 litres



Note: The water may appear cloudy during flushing - this is normal.


It is safe to drink the water only after completing the flushing process, which ensures clear, pure, and fresh-tasting water.

Place a container under the dispensing spout and briefly press the Cold Water  button. The water bar will dispense 5 liters of cold water.

Pressing any button will stop the dispensing, while pressing 'Continue' will resume it. When the water filter is installed correctly, a confirmation message will appear, and the Water Bar will beep twice, signaling that you can proceed to flush the new filter.

Edge+ Water Filter and UV-C Lamp Replacement


Replacing the UV lamp:



1. Unplug the device from the electrical socket.




2. Remove the top panel.



3. Firmly hold both sides of the UV-C lamp head and pull it straight up out of the Water Bar.




4. Install the new UV-C lamp.




5. Reattach the top panel.



6. Plug the device back into the electrical socket.



7. Press the 'Menu and Personal Drinks' button > 'Settings' > 'Water Filter & UV-C Lamp' > 'OK'. Select Update UV-C lamp, choose 'New UV-C lamp', and press 'OK' to confirm.



8. When the UV-C lamp is correctly installed, a confirmation message will appear, the Water Bar will beep twice, and the UV-C icon will return to its white state.

Note:

If the UV-C lamp is not installed correctly, has expired, or is not a genuine replacement part, an error message will remain on the display until the issue is resolved. During this time, you will not be able to dispense water.

If there is an error with the UV-C system, an error message will remain on the display until the issue is resolved, and you will not be able to dispense water. please contact our Customer Service at 22441828 for assistance.