



**Filter and UV-C  
Lamp Kit  
T7 Water  
Purifier**







This kit contains a filter  
and a UV-C lamp

## How to replace the filter?


- 1 Remove the top cover.




- 2 Press the PUSH button and pull the filter upwards using the extraction band.




- 3 Pull the filter outside and dispose of it.




- 4 Remove the wrapper from the new filter.





- 5 Insert the filter until you hear a click.



- 6 Reset the filter's counter by entering the "Filter/Lamp replacement" sub-menu: MAIN MENU > FILTER/LAMP REPLACEMENT
1. Press **OK**.
  2. Scroll to "Filter" using the **▲** and **▼** buttons and choose **OK**.
  3. Choose the "Yes" option and confirm using the **OK** button.
  4. Replace the top cover.

- 7 Place a container under the spout, press the cold water  button for 2 minutes. Wait 10 minutes. Press the cold water button again, until water starts running.






# How to change the UV-C lamp?

**Warning:** It is forbidden to turn on the UV-C lamp outside the device. Using it not according to the intended use or damage to the UV lamp socket may cause the escape of UV-C radiation which is harmful to the eyes and skin. The water purifier should not be operated in case of defect or damage to the lamp.


- 1** Remove the top cover.




- 2** Pull the lamp upwards.




- 3** Remove the new lamp from its wrapper (avoid touching the lamp itself).



- 4** Insert the new lamp into the water purifier.






- 5** Scroll to "NEW UV LAMP" using the  and  buttons and press **OK**.  
Replace the top cover.



**Enjoy!**



# Troubleshooting

	Symptom	Resolution
1	Slow water flow	<ul style="list-style-type: none"> <li>Remove and re-insert the filter, making sure that it fits into the filter holder completely.</li> <li>If the problem persists, contact our Service Department.</li> </ul>
2	Cold water keeps running for a while after releasing the button	<ul style="list-style-type: none"> <li>Wait for about 10 minutes and try again.</li> <li>If the problem persists, contact our Service Department.</li> </ul>
3	No water comes out (cold only)	<ul style="list-style-type: none"> <li>Remove and re-insert the lamp.</li> <li>Unplug and re-plug the device to the power source.</li> <li>Press the cold water  button for 2 minutes in order to release the air from the cold water tank.</li> <li>If the problem persists, contact our Service Department.</li> </ul>
4	Hot and cold water come out simultaneously	<p><b>Possibility A</b></p> <p>If you pressed the cold water  button but hot water come out, dispense hot water for 2-3 minutes.</p> <p><b>Possibility B</b></p> <p>If you pressed the hot water  button but cold water come out, dispense cold water for 2-3 minutes.</p> <ul style="list-style-type: none"> <li>If the problem persists, contact our Service Department.</li> </ul>